

Board For  
EG91X-XX

- SDA
- SCL
- RST
- DP0

Powered by  
Quectron

USBC1

SW3

SW4

SW5

MIC

SPK

USB

PWR/AL

Board For  
EG91X-XX

- SDA
- SCL
- RST
- DP0

Powered by  
Quectron

USBC1

SW3

SW4


SW5

MIC

SPK

USB

PWR/AL



SD 2.0

